

EXTECH®

EC505 pH Electrode



Installation Instructions

1. Turn meter power “off.”
2. Remove retaining collar holding probe on meter.
3. Pull, with a gentle “rocking” motion, to remove old probe.
4. Reverse order to install new probe. Do not touch contacts.
5. Before first use or after extended storage, soak the electrode (with its cap removed) in a pH 4 solution for about 10 minutes. Rinse briefly in deionized water.

Electrode Storage Instructions

Store in storage cap with sponge moistened with 4 buffer or KCl solution.

Rinse in deionized water briefly before use.

For further instructions, see instrument instruction manual.

This probe is compatible with: EC500 ExStik® Conductivity Meter

Contact Customer Support

Customer Support Telephone List: <https://support.flir.com/contact>

Calibration, Repair, and Returns: repair@extech.com

Technical Support: <https://support.flir.com>

Copyright © 2021 Teledyne FLIR LLC

All rights reserved including the right of reproduction in whole or in part in any form
www.extech.com