

# EXTECH®

## CL205 Chlorine Electrode

### Installation Instructions

1. Turn meter power “off.”
2. Remove retaining collar holding probe on meter.
3. Pull, with gentle “rocking” motion, to remove old probe.
4. Reverse order to install new probe. Do not touch contacts.



### Electrode Storage Instructions

1. After use, rinse with deionized water.
2. Gently dry with a paper towel.
3. Store dry with storage cap attached.

For further instructions, see the meter’s User Manual.

### This probe is compatible with:

CL200 ExStik® Chlorine Meter  
PH100 ExStik® pH Meter  
PH110 ExStik® pH Meter  
RE300 ExStik® ORP Meter

### 6 Month Guarantee

### Contact Customer Support

---

Customer Support Telephone List: <https://support.flir.com/contact>

Calibration, Repair, and Returns: [repair@extech.com](mailto:repair@extech.com)

Technical Support: <https://support.flir.com>

Copyright © 2021 Teledyne FLIR LLC

All rights reserved including the right of reproduction in whole or in part in any form

[www.extech.com](http://www.extech.com)